Quick User Guide

**** Warequip accepts no responsibility for equipment that is operated incorrectly, or not in accordance with operation manuals.***

POWERED CAGEMATE

LOAD CAPACITY – 450kg

Evenly distributed loads as recommended

DO NOT OVERLOAD or obstruct operator view with high loads.

POWER – ON/OFF SWITCH

Turn key switch to on position for normal operation.
If powered status light flashes there may be a fault, please contact your supplier.

EMERGENCY STOP

Stops the unit when reversing.



PADDLE LEVER

Push lever forward for forward motion.
Push lever down for reverse motion.
(Buzzer should sound in reverse)
FORWARD MOTION IS ALWAYS RECOMMENDED!

SPEED CONTROLLER

Adjust speed for load and the speed required – WALKING PACE IS RECOMMENDED!

Please ensure you are familiar with the manual and the correct operating instructions.

If in doubt contact supplier before use.

Quick User Guide

POWERED CAGEMATE

ELECTRONIC BRAKE RELEASE

Push to disable drive motor when power is on.

FREE WHEEL LEVER

Push to disable brake motor to enable free wheel if batteries are flat.
This enables trolley to be used normally with no power drive engaged.
ALWAYS do this on a level surface.

BATTERY INDICATOR

When low connect to charger as soon as possible



CHARGING

Unit has an external charger which is located in a compartment underneath the deck at the end of the controls.

Charging point is located on the left hand side of the handle.



Plug lead into female position and then into powerpoint – charge with keyswitch in OFF POSITION.

OVERNIGHT CHARGE IS RECOMMENDED

Please ensure you are familiar with the manual and the correct operating instructions.

If in doubt contact supplier before use.