

* Warequip accepts no responsibility for equipment that is operated incorrectly, or not in accordance with operation manuals.

LIFT 'N' BUDDY



LOAD CAPACITY - 225 KG

Evenly distributed loads as recommended DO NOT OVERLOAD or obstruct operator view with high loads.



POWER – ON/OFF SWITCH

When standing behind the LIFT 'N' BUDDY the Key switch is located on the right hand side of the body, turn the Key switch to on position for normal operation. If powered status light flashes there may be a fault, please contact your supplier.

PLACEMENT

Move the load to the location, as with an ordinary hand truck

CONTROLS

At the location, press the 'lift up' button until the LIFT 'N' **BUDDY** is at the correct height. With the load at the correct height, use as a normal hand truck. With the load above the surface, press 'lift down' to lower the load. Then pull back from underneath the load.

CHARGING

Unit has an external charger which is supplied separately to the machine

The charging point is located on the back right side of the unit.

Take the cables from charger and using your left hand plug the BLACK clamp on the BLACK charge point (left hand side) then using your right hand plug the RED clamp on the RED charge point (Right hand side) plug the charger lead into the plug on the charger box (the plug will only fit the correct end) and then into power point.

If a flashing light appears please contact your supplier.

OVERNIGHT CHARGE IS RECOMMENDED

ONLY USE THE CHARGER SUPPLIED WITH THE UNIT.



Please ensure you are familiar with the manual and the correct operating instructions.

If in doubt contact supplier before use.





