

\* Warequip accepts no responsibility for equipment that is operated incorrectly, or not in accordance with operation manuals.

## POWERED STAIRCLIMBER L1

**295 KG**

**LOAD CAPACITY** – 295 KG with two people 204kg with one

Evenly distributed loads as recommended

**DO NOT OVERLOAD** or obstruct operator view with high loads.



### POWER – ON/OFF SWITCH

When standing behind the LE1 the ON/OFF switch is located on the right hand side of the body, turn the ON/OFF switch to on position for normal operation.

A second switch is located on the rear of the unit near the wheels. Both switches must be in the on position for use.



### CONTROLS

At the location, press the 'lift up' button until the LE1 is at the correct height.

With the load at the correct height, pull the lever under the right handle to release the brake and move forward.

With the load above the surface, press 'lift down' to lower the load. Then pull back from underneath the load.



### PLACEMENT

Move the load to the location, as with an ordinary hand truck, then use the up/down buttons to manoeuvre up the stairs.





# Quick User Guide

## POWERED STAIRCLIMBER LE1

### **BATTERY INDICATOR**

This unit is not equipped with a battery indicator. Please ensure you regularly charge the unit to avoid failure.



### **CHARGING**

Unit has an external charger which is supplied separately to the machine

The charging point is located on the

Plug the charger lead into the plug on the LE1 (the plug will only fit the correct end) and then into power point. – Charge with ON/OFF switch in the OFF POSITION.

Turn the switch on the charger to the on position, a red light will come on and the amp meter will activate.

If a flashing light appears please contact your supplier.

**OVERNIGHT CHARGE IS RECOMMENDED**

**ONLY USE THE CHARGER SUPPLIED WITH THE UNIT.**



*Please ensure you are familiar with the manual and the correct operating instructions.*

*If in doubt contact supplier before use.*