

* Warequip accepts no responsibility for equipment that is operated incorrectly, or not in accordance with operation manuals.

SPIN GO



LOAD CAPACITY – Driver plus 130kg on a level surface Evenly distributed loads as recommended DO NOT OVERLOAD or obstruct operator view with high loads.

OPERATION

The unit is designed to be pushed into position with powered assistance. The front of the unit is the end with the cargo platform.



POWER – ON/OFF SWITCH

When standing on the unit the Key switch is located on the front side of the body, turn the Key switch to position 1 for normal operation.

Position 2 allows manual override using green button to the right of switch.



EMERGENCY STOP BUTTON

Push to disable the SPIN GO when power is on. This will shut down all systems apart from the brake. This button should not be used as a normal form of braking or as an on off switch. To reset, simply pull on the button until you feel it change position. The Spin Go has two stop buttons, one located near key switch, second one next to the up and down buttons.



CONTROLS

When standing on the SPIN GO ensure the doors are closed behind you.

Push the green button at the top on the right hand side to lift the platform, release to stop.

Push the green button at the bottom on the right hand side to lower the platform, release to stop.



SPIN GO



BATTERY INDICATOR

When fully charged the lights will illuminate to show 100%, as you use the Spin GO the lights will change to show the level. Once the charges falls to 40% we recommend charging, a red light will flash for approximately 10 minutes before the unit loses all charge.

CHARGING

The charging point is located on the front side on the SPIN GO's body.



Plug the charger lead into the plug on the Spin Go (the plug will only fit the correct end) and then into power point. – Charge with key switch in the OFF POSITION. A red light will come on showing charging has begun. If a flashing light appears please contact your supplier.

OVERNIGHT CHARGE IS RECOMMENDED

ONLY USE THE CHARGER SUPPLIED WITH THE UNIT.

EMERGENCY USE ONLY

If the Spin Go is in the raised position and will not lower pull the red lever on the front of the unit to lower.



Please ensure you are familiar with the manual and the correct operating instructions.