

\* Warequip accepts no responsibility for equipment that is operated incorrectly, or not in accordance with operation manuals.

# SULO2P2GO




LOAD CAPACITY - 500kg Evenly distributed loads as recommended DO NOT OVERLOAD or obstruct operator view with high loads.



POWER – ON/OFF SWITCH Turn key switch clockwise to on position for normal operation



**DEAD MAN SWITCH PUSH** for OFF – for normal operation **PULL for ON** 



PADDLE LEVER Push lever forward for forward motion. Push lever down for reverse motion. (Buzzer should sound in reverse) FORWARD MOTION IS ALWAYS RECOMMENDED!



SPEED CONTROLLER Adjust speed for load and the speed required -WALKING PACE IS RECOMMENDED!



Please ensure you are familiar with the manual and the correct operating instructions.

If in doubt contact supplier before use.



# SULO2P2GO



### FREE WHEEL LEVER

Push to disable brake motor to enable free wheel if batteries are flat.

This enables trolley to be used normally with no power drive engaged.



# BRAKE CASTOR

Press pedal to engage brake and disengage brakes as required.

Brake should be used if stopped on incline.



## **CHARGE POINT**

Plug lead into female position and then into powerpoint - charge with keyswitch in OFF POSITION.

OVERNIGHT CHARGE IS RECOMMENDED



## **BIN LOADING**

Remove chain from opening, simply push the bin on to the SULO2P2GO. The ramp will pivot and lift the bin on to the unit. Ensure you place the chain back into position before moving or loading the next bin.

To unload, open the chain and pull the bin towards you. The pivot will lower the bin to the ground ready to be moved away. Ensure you don't stand in line with the bin as you pull.



Please ensure you are familiar with the manual and the correct operating instructions.

If in doubt contact supplier before use.